

TABLE DRIVE ASSEMBLY

Ref. Dwg. 070-001-840 Rev. H

Effective To Serial No. 95151

| ITEM | PART NUMBER | DESCRIPTION | ITEM | PART NUMBER | DESCRIPTION |
|------|-------------|--|------|-------------|---|
| 1 | 070-001-842 | Crank Housing Ass'y. (Items 2 & 3) | 29a | 070-001-915 | Washer Retainer |
| 2 | 070-001-841 | Housing | 30 | 913-423-140 | Roll Pin $\frac{1}{8}$ x $\frac{7}{16}$ |
| 3 | 900-205-053 | Flange Bearing | 31 | 818-233-062 | Screw Phil Rd. Hd. Sems 8-32 x $\frac{3}{8}$ |
| 4 | 070-001-843 | Eccentric Bolt | 32 | | |
| 5 | 070-001-844 | Spring, Actuator | 33 | 710-501-004 | Grease Fitting (Alemite #1641) |
| 6 | 070-001-845 | Spring | 34 | 809-874-365 | Screw Hex Hd, $\frac{1}{2}$ -20 x $2\frac{1}{2}$ |
| 7 | 070-001-857 | Roller | 34a | 809-873-405 | Screw Hex Hd., $\frac{1}{2}$ -13 x $2\frac{1}{2}$ |
| 8 | 070-001-861 | Link And Hub Ass'y. | 35 | 844-074-002 | Nut, Stover Lock $\frac{1}{4}$ -20 |
| 9 | 070-001-862 | Link (Hex Hole In Smaller Boss) | 35a | 844-073-002 | Nut, Stover Lock $\frac{1}{2}$ -13 |
| 10 | 070-001-863 | Pin (Hex Shoulder) | 36 | 070-001-877 | Eccentric |
| 11 | 070-001-866 | Pin ($\frac{3}{32}$ Dia. Holes) | 37 | 070-001-849 | Washer |
| 12 | 070-002-652 | Bushing | 38 | 840-070-002 | Nut Flex Loc $\frac{7}{16}$ -20 |
| 13 | 912-137-200 | Groove Pin $\frac{3}{16}$ x $1\frac{1}{4}$ " Type 2 | 39 | 000-021-880 | Rod End Ass'y. (Items 40, 41, 42, 43) |
| 14 | 880-139-120 | Shoulder Screw $\frac{1}{4}$ x $\frac{3}{8}$ x 10-24 | 40 | 919-000-600 | Retaining Ring (N5000-137) |
| 15 | 838-939-002 | Nut, ESNA 10-24 | 41 | 000-021-879 | Rod End |
| 16 | 913-415-120 | Roll Pin $\frac{3}{32}$ x $\frac{3}{4}$ | 42 | 000-021-878 | Spacer |
| 17 | 070-001-868 | Latch Block And Arm Ass'y. | 43 | 000-021-881 | Bearing, Ball |
| 18 | 070-001-865 | Block, Latch | 44 | 840-182-002 | Nut, Flex-loc, $\frac{5}{8}$ -18 |
| 19 | 070-001-867 | Arm, Latch | 45 | 835-582-002 | Nut - Hex Jam, $\frac{5}{8}$ -18 |
| 20 | 913-423-120 | Roll Pin $\frac{1}{8}$ x $\frac{3}{4}$ | 46 | 070-001-848 | Link |
| 21 | | | 47 | 070-001-870 | Screw, Soc. Hd. Shoulder |
| 22 | 070-002-735 | Bearing Assembly (Items 23 and 24) | 48 | 844-081-002 | Nut Stover $\frac{5}{8}$ -11 |
| 23 | 070-002-780 | Cup, Bearing | 49 | 070-006-722 | Yoke Weldment |
| 24 | 070-002-824 | Cone & Seal, Bearing | 50 | 070-007-310 | Bushing |
| 25 | 070-002-739 | Bearing Ass'y. (Items 26 & 27) | 51 | 070-007-311 | Sleeve |
| 26 | 070-002-776 | Cup, Bearing | 52 | 070-006-721 | Bushing |
| 27 | 070-002-777 | Cone, Bearing | 53 | 190-001-490 | Bearing |
| 28 | 070-001-836 | Shield | 54 | 809-873-525 | Screw - Hex Hd. Cap SAE #8 |
| 29 | 070-002-835 | Washer Retainer | 55 | 844-073-002 | Locknut |

TABLE DRIVE ASSEMBLY

REF. DWG. 070-001-840 REV. H

Effective to serial no. 95151

NOTE: Items 26 and 36 may be purchased
as an assembly - specify part
no. 070-002-779.

