

TABLE & BRACKET ASSEMBLY




TABLE & BRACKET ASY



TABLE & BRACKET ASSEMBLY

ITEM	QTY	PART #	DESCRIPTION
1	2	090-005-505	FRONT BRACKET WELDMENT
2	1	090-005-613	ROD ASSEMBLY, LONG
3	19	844-057-002	NUT, STOVER LOCK, 5/16 - 18
4	1	090-005-637	PIVOT SUPPORT BRACKET
5	2	808-557-140	SCREW, BUTTON HEAD CAP, 5/16 - 18 X 7/8
6	2	835-549-002	NUT, HEX JAM, 1/4 - 20
7	1	808-549-200	SCREW, BUTTON HEAD CAP, 1/4 - 20 X 1 1/4
8	17	808-557-120	SCREW, BUTTON HEAD CAP, 5/16 - 18 X 3/4
9	1	090-005-651	SPOT TIE ROD ASSEMBLY
10	1	090-005-615	ROD ASSEMBLY, SHORT
11	1	090-005-251	RESPOT TIE ROD ASSEMBLY
12	4	809-849-165	SCREW, HEX, 1/4 - 20 X 1
13	2	844-069-002	NUT, STOVER LOCK, 7/16 - 14
14	2	809-869-285	SCREW, HEX, 7/16 - 14 X 1-1/2
15	9	808-549-120	SCREW, BUTTON HEAD CAP, 1/4 - 20 X 3/4
16	1	090-005-656	REAR BRACKET SHIM
17	13	844-049-002	NUT, STOVER LOCK, 1/4 - 20
18	1	090-005-536	MOUNTING BRACKET

ITEM	QTY	PART #	DESCRIPTION
------	-----	--------	-------------