

**294-115-024 Drive Shaft Assembly**

	NUMBER	DESCRIPTION
1	A-0337	Drive Shaft
2	A-0995	Drive Wheel, Right Side
3	A-0994	Drive Wheel, Left Side
4	03-004	Pillow Block
5	A-0521	Drive Shaft Sprocket
6	A-0041	Bearing Drive Shaft End
7	01-078	Roll Pin, 1/8 X 3/4
8	01-087	Roll Pin, 3/16 X 2
9	A-8011	Drive Shaft Spacer
10	A-00411	Bearing Lock Collar With Setscrew
11	01-082	Pin, 3/16 X 1 1/8, Roll, Plated

