

Drive Shaft Assembly

	NUMBER	DESCRIPTION
1	A-0337	Drive Shaft
2	294-115-404	Drive Wheel
3	294-012-120	Drive Shaft Bearing Block Assembly
4	A-0521	Drive Shaft Sprocket
5	01-087	Roll Pin, 3/16 x 2
6	01-082	Roll Pin, 3/16 x 1-1/8
7	294-012-216	Collar
8	01-007	Set Screw, 8-32 x 1/4
9	294-012-118	Drive Shaft Bearing Block
10	294-012-119	Drive Shaft Bearing
11	294-115-131	Retaining Ring

